

# Colonial Woodwork Details

by


**MORGAN**



*Consult an Architect!*

**MORGAN WOODWORK ORGANIZATION**

OSHKOSH NEW YORK CHICAGO TOLEDO BALTIMORE JERSEY CITY GREENSBORO WILMINGTON NEW HAVEN



INDEX TO  
**COLONIAL WOODWORK**  
 BY  
**MORGAN**

ITEM	DESIGN NUMBERS	SHEET	ITEM	DESIGN NUMBERS	SHEET
Blinds	M-500 M-503 M-504	15	Flower Box	M-552	13
Bookcase	M-1550	47	Frames (Window)	M-250 M-251 M-252	14
"	M-1551	48	" "	M-253 M-254 M-255	14
Book Shelf	M-1552	49	Frames (Circular)	M-256 M-257	13
Brackets	M-553	13	" (Louvre)	M-258 M-259	13
Breakfast Nook Set	M-550	30	Interior Trim	No. 1	31
Broom Closet and Kitchen Cabinet	M-1569	51	" "	No. 2	32
China Case	M-1553	40	Ironing Boards	M-1567 M-1568	49
" "	M-1554	40	Kitchen Cabinets	M-1570 M-1569	51
" "	M-1555	41	Linen Cases	M-1565 M-1566	50
" "	M-1556	42	Louvres	M-258 M-259	13
" "	M-1557	43	Mantels	M-1450	33
" "	M-1558	44	" "	M-1451	34
" "	M-1559	44	" "	M-1452	35
" "	M-1560	45	" "	M-1453	36
" "	M-1561	46	" "	M-1454	36
" "	M-1562	46	" "	M-1455	37
Doors, Exterior	M-100	1-6-10-12	" "	M-1456	38
" "	M-101	3	" "	M-1457	38
" "	M-102	2-5	" "	M-1458	39
" "	M-103	7	Medicine Cabinets	M-1563 M-1564	49
" "	M-104	8	Mouldings, Exterior	M-700 to M-713	16
" "	M-105	9	Paneling, Wall	M-1300 M-1301 M-1251	17
" "	M-106	11	Porch Work	M-1950 to M-1959	52
Doors, Garage	M-1750 M-1751	53	Sash, Windows	M-350 M-351 M-352	13
" "	M-1752 M-1753	53	" "	M-366 M-367 M-368	13
Doors, Interior	M-1050 M-1051 M-1052	25	" "	M-369 M-370 M-371 M-372	13
" "	M-1053 M-1054	26	Seat	M-551	30
" "	M-1055 M-1056	27	Shutters	M-501 M-502 M-505	15
" "	M-1057 M-1058	29	Sidelight Sash	M-362	5-6
" "	M-1059 M-1060	29	Stairways	M-850	18
Door, Interior (Sash)	M-1080 M-1081	28	" "	M-851	19
Entrance Frames	M-1	1	" "	M-852	20
" "	M-2	3-4	" "	M-853	21
" "	M-3	2	" "	M-854	22
" "	M-4	5	Stair Parts	M-865 to M-896	23-24
" "	M-5	6	Transom	M-361	1
" "	M-6	7	" "	M-363	5
" "	M-7	8	" "	M-364	6
" "	M-8	9	" "	M-364A	11
" "	M-9	10	Trim Interior	No. 1	31
" "	M-10	11	" "	No. 2	32
" "	M-11	12	Wall Paneling	M-1300 M-1301 M-1251	17
Exterior Mouldings	M-700 to M-713	16	Windows	See Sash, Windows	13

Digitized by



ASSOCIATION  
FOR  
PRESERVATION  
TECHNOLOGY,  
INTERNATIONAL

[www.apti.org](http://www.apti.org)

BUILDING  
TECHNOLOGY  
HERITAGE  
LIBRARY

<https://archive.org/details/buildingtechnologyheritagelibrary>


From the collection of:

Mike Jackson, FAIA


**COLONIAL ENTRANCE M-1**

MORGAN

**INDEX SHEET NO. I**



## SECTION





## COLUMN BASE

# COLONIAL ENTRANCE M-3


MORGAN

## INDEX SHEET NO.-2

PLAN THRU PILASTER  
SCALE 3'-1"-0"



ELEVATION  
SCALE 1/4"-1"-0"



SCALE 3'-1"-0"

FRAME M-3

DOOR

M-102

3'-0"

BRICK'

PLAN

FRONT ELEVATION  
SCALE 3/4"-1"-0"

3'-4"


FRAME

SECTION

**COLONIAL ENTRANCE M-2**

MORGAN

# INDEX SHEET NO.3



## SECTION

## COLUMN

FRONT ELEVATION  
SCALE  $\frac{3}{4}$ " = 1'-0"


# PILASTER

PLANS & DETAILS  
ON REVERSE SIDE


# COLONIAL ENTRANCE M-2

MORGAN



## INDEX SHEET NO. 4




COLUMN & PILASTER CAPS  
SCALE 3"-1'-0"



BASE OF COLUMNS  
SCALE 3"-1'-0"



PROFILE ON & THRU HEAD  
SCALE 3"-1'-0"







# COLONIAL ENTRANCE M-4


MORGAN

INDEX SHEET NO. 5



## PLANS OF PILASTERS FULL SIZE



## SECTION




SIDELIGHT SILL PROFILE




# COLONIAL ENTRANCE M-5

MORGAN


## INDEX SHEET NO.-6



PLANS OF  
PILASTERS  
FULL SIZE




PROFILE ON C  
SCALE 3"-1'-0"





FRONT ELEVATION  
SCALE  $\frac{3}{4}$ "=1'-0"

ELEVATION  
SCALE  $\frac{1}{4}$ "=1'-0"



SIDELIGHT  
SILL PROFILE




FRAME PLAN

# COLONIAL ENTRANCE M-6


MORGAN

INDEX SHEET NO.-7

PROFILE ON C  
SCALE 3"-1'-0"




ELEVATION  
SCALE  $\frac{1}{4}$ "=1'-0"



SECTION

FRONT ELEVATION

3'-4" SCALE  $\frac{3}{4}$ "=1'-0"




FRAME

PLAN

BRICK


BASE & STOOL




# COLONIAL ENTRANCE M-7

MORGAN

## INDEX SHEET NO.-8




SECTION



# COLONIAL ENTRANCE M-8

MORGAN


## INDEX SHEET NO. 9




SECTION

FRONT ELEVATION

SCALE  $\frac{3}{4}'' = 1'-0''$



ELEVATION  
SCALE  $\frac{1}{4}'' = 1'-0''$



# COLONIAL ENTRANCE M-9

MORGAN




INDEX SHEET NO.-10

FULL SIZE PROFILE  
THRU HEAD

FRAME M-9

DOOR M-100


ELEVATION  
SCALE  $\frac{1}{4}'' = 1'-0''$



SECTION

FRONT SCALE

$3'-4''$   $\frac{3}{4}'' = 1'-0''$



FULL SIZE PROFILE  
THRU PILASTER CAP

**COLONIAL ENTRANCE M-10**

**MORGAN**

**INDEX SHEET NO.-11**

## FULL SIZE PLAN OF PILASTERS

FRAME M-10

TRANSOM M-364-A

DOOR M-106

Architectural floor plan diagram showing two rectangular rooms side-by-side. The left room is labeled 6'-8" wide by 3'-0" deep. The right room is labeled 6'-4 3/4" wide by 3'-0" deep. A central corridor is 3'-0" wide. The overall width of the building is 11'-3 1/2". Foundation walls are shown at the bottom, and doorways are indicated by dashed lines.

**FRONT ELEVATION**  
**SCALE  $\frac{3}{4}$ " - 1'-0"**

## SECTION


## FULL SIZE TRANSOM PROFILE

Fall 1930


# COLONIAL ENTRANCE M-II

MORGAN

INDEX SHEET NO. 12




SECTION




FRONT ELEVATION  
SCALE  $\frac{3}{4}$ "=1'-0"

FULL SIZE PROFILE THRU  
HEAD ON C



ELEVATION  
SCALE  $\frac{1}{4}$ "=1'-0"



FRAME


PLAN

BRICK


# COLONIAL WINDOWS




# INDEX SHEET NO:13



HALF FULL SIZE DETAILS OF SASH  
 $1\frac{1}{4}$ " THICK




$1\frac{3}{8}$ " THICK




HALF FULL SIZE DETAIL OF  
CHECK RAIL



M-369




M-370




M-371

M-372


TYPICAL SASH LAYOUTS  
SCALE  $\frac{1}{4}$ " = 1'-0"




M-366




M-367




M-368




M-350




M-351




M-352




ELEVATION  
1'-5 $\frac{1}{2}$ " R.O.




PLAN  
SCALE  $\frac{3}{4}$ " = 1'-0"




SECTION



ELEVATION  
2'-8 $\frac{1}{2}$ " R.O.




PLAN




WINDOW BOX M-552


BRACKETS M-553  
ELEVATION  
SCALE  $\frac{3}{4}$ " = 1'-0"




ELEVATION




FRAME M-256



HEAD



JAMB



SILL

DETAIL OF FRAMES M-256-7  
SCALE  $\frac{1}{2}$ " = 1'-0"


# COLONIAL WINDOW FRAMES

MORGAN


# INDEX SHEET NO:14

WINDOW FRAMES  
SCALE  $\frac{1}{2}'' = 1'-0''$


## FRAMES FOR WESTERN OPENINGS






## FRAMES FOR BOTH EASTERN & WESTERN OP'NGS






## FRAMES FOR EASTERN OPENINGS



## HEAD SECTIONS



## JAMB SECTIONS




## SILL SECTIONS


# COLONIAL SHUTTERS

MORGAN


# INDEX SHEET NO. 15




SHUTTER M-501




SHUTTER M-502




BLIND M-500





BLIND M-503




BLIND M-504




SHUTTER M-505




FULL SIZE SECTION A-A




SECTION E-E




SECTION D-D



FULL SIZE SECTION C-C




FULL SIZE SECTION B-B



SECTION F-F


## FULL SIZE EXTERIOR MOULDINGS



# COLONIAL PANELLING

MORGAN


INDEX SHEET NO:17




FULL SIZE OF CORNICE A




F.S.D.




WALL PANELLING WITH M-1251  
SCALE  $\frac{3}{4}'' = 1'-0''$



WALL PANELLING M-1301  
SCALE  $\frac{3}{4}'' = 1'-0''$



FULL SIZE DETAIL M-1301




WALL PANELLING M-1300  
SCALE  $\frac{3}{4}'' = 1'-0''$


# COLONIAL STAIRWAY M-850

MORGAN



INDEX SHEET NO. 18



PLAN NO. 1



PLAN NO. 2  
SCALE 1/4"-1'-0"



PLAN


COLONIAL STAIRWAY M-851

MORGAN

**INDEX SHEET NO.-19**

Fall 1930

© 1930, Morgan Woodwork Organization





# COLONIAL STAIRWAY M-852

MORGAN

INDEX SHEET NO.-20


FULL SIZE PROFILE OF STAIR NOSING

FULL SIZE SECTION  
OF HANDRAIL  
M. - 874




PLAN NO. 2  
SCALE  $\frac{1}{4}$ "-1'-0"

PLAN NO. 1




ELEVATION  
SCALE  $\frac{3}{4}$ "-1'-0"




PLAN

FULL SIZE BASE OF ANGLE & LANDING NEWEL



FULL SIZE DETAIL OF  
UPPER PART OF NEWEL

SQUARE








# COLONIAL STAIRWAY M-853

MORGAN

## INDEX SHEET NO.-21

Fall 1930






# COLONIAL STAIRWAY M-854







MORGAN

## INDEX SHEET NO. 22

Fall 1930




## DETAILS OF STAIR PARTS





STARTING STEPS & RISERS  
SCALE 3/4" = 1'-0"



STAIR RAILS  
SCALE 1/2" = HALF FULL SIZE



BALUSTERS






STAIR BRACKETS  
SCALE 1/2" = 1'-0"

# COLONIAL STAIR NEWELS

MORGAN

INDEX SHEET NO. 24

STAIR      NEWEL      POST      DETAILS  
SCALE  $\frac{1}{2}$ " = 1'-0"




# COLONIAL DOORS M-1050-1-2

**Morgan**

INDEX SHEET NO.-25

Fall 1930




DOOR M-1050

DOOR M-1051

DOOR M-1052

FULL SIZE SECTIONS OF DOORS  $1\frac{3}{8}$ " THICK




DOOR M-1050

DOOR M-1051

DOOR M-1052

2'-8"


2'-6", 2'-10" & 3'-0" ALSO



2'-8"


2'-6", 2'-10" & 3'-0" ALSO

INTERIOR DOORS SCALE  $\frac{3}{4}":1'-0"$



6'-10" & 7'-0" ALSO

6'-8"



DOOR M-1050

DOOR M-1051

DOOR M-1052


FULL SIZE SECTIONS OF DOORS  $1\frac{3}{4}$ " THICK

COLONIAL DOORS M-1053-4


**MORGAN**

**INDEX SHEET NO. 26**

Fall 1930




DOOR M-1053




DOOR M-1054


FULL SIZE SECTIONS OF DOORS  $1\frac{3}{8}$ " THICK




2'-6", 2'-10" & 3'-0" ALSO  
INTERIOR DOORS



SCALE  $\frac{3}{4}'' = 1'-0''$



DOOR M-1053




## FULL SIZE SECTIONS

DOOR M-1054  
OF DOORS 1 $\frac{3}{4}$ " THICK



# COLONIAL DOORS M-1055-6

MORGAN

# INDEX SHEET NO. 27



FULL SIZE SECTION OF DOORS  $1\frac{3}{8}$ " THICK




FULL SIZE SECTION OF DOORS  $1\frac{3}{8}$ " THICK



# COLONIAL DOORS M-1080-1

MORGAN

INDEX SHEET NO. 28



FULL SIZE SECTIONS OF DOORS 1 3/8" THICK



FULL SIZE SECTIONS OF DOORS 1 3/4" THICK

# COLONIAL DOORS M-1057-8-9-60

MORGAN

INDEX SHEET NO. 29

6'-8"  
6'-10" & 7'-0" ALSO


6'-8"  
6'-10" & 7'-0" ALSO  
0'-7" & 0'-10" ALSO

6'-8"

DOOR M-1058

2'-8"  
2'-6", 2'-10" & 3'-0" ALSO

SCALE  $\frac{3}{4}'' = 1'-0''$



DOOR M-1057


6'-8"  
6'-10" & 7'-0" ALSO

2'-8"  
2'-6", 2'-10" & 3'-0" ALSO

INTERIOR DOORS

DOOR M-1060

2'-8"  
2'-6", 2'-10" & 3'-0" ALSO



FULL SIZE  
SECTION OF  
DOORS 1 3/4  
THICK

DOOR M-1059


6'-8"  
6'-10" & 7'-0" ALSO

2'-8"  
2'-6", 2'-10" & 3'-0" ALSO

# COLONIAL NOOK M-550

MORGAN

# INDEX SHEET NO. 30




END ELEVATION OF TABLE  
SCALE  $\frac{3}{4}'' = 1'-0''$

SIDE ELEVATION OF TABLE

• NOTE •  
COLONIAL SEATS M-551  
INTERIOR & EXTERIOR  
ARE SIMILAR.

BREAKFAST NOOK M-550



END ELEVATION - BENCH - FRONT ELEVATION  
SCALE  $\frac{3}{4}'' = 1'-0''$


END ELEVATION OF BENCH  
SCALE 3" = 1' - 0"

HALF END ELEVATION OF TABLE  
SCALE 3" = 1' - 0"



# COLONIAL TRIM NO. I

MORGAN


# INDEX SHEET NO. 31



FULL SIZE PROFILE  
OF WINDOW STOOL &  
APRON.




FULL SIZE OF BASE



# COLONIAL TRIM NO 2

MORGAN

# INDEX SHEET NO. 32



# COLONIAL MANTEL M-1450

MORGAN

INDEX SHEET NO:33

FULL SIZE PROFILE  
OF MANTEL

FULL SIZE PROFILE  
THRU FRAME

MANTEL M-1450

FIREBRICK

4'-4 $\frac{1}{2}$ "

2 $\frac{1}{2}$ " 5 $\frac{1}{2}$ "

4'-2"

FIREBRICK

4'-2 $\frac{1}{2}$ " 3 $\frac{1}{2}$ "


3'-0"

2'-0"


5 $\frac{1}{2}$ " 2 $\frac{1}{2}$ "

FRONT ELEVATION

SECTION





ELEVATION  
SCALE  $\frac{1}{4}$ "=1'-0"





# COLONIAL MANTEL M-1451

MORGAN

INDEX SHEET NO.34



FULL SIZE PROFILE  
OF MANTEL SURROUND





# COLONIAL MANTEL M-1452



MORGAN

INDEX SHEET NO:35

FULL SIZE PROFILE  
OF MANTEL




FULL SIZE  
PROFILE THRU  
FRAME




# COLONIAL MANTELS M-1453-4






## INDEX SHEET NO. 36



FULL SIZE DETAIL OF  
BRACKET ORNAMENT




ELEVATION  
SCALE  $\frac{1}{4}''=1'-0''$




FULL SIZE  
SECTION OF  
PANEL MOLD

BRACKET ELEVATION - SEC.  
SCALE 3"-1'-0"



ELEVATION  
SCALE  $\frac{1}{4}''=1'-0''$



FULL SIZE DETAIL OF QUARTER OF ORN.

PLANS - SECTIONS AND PROFILES SIMILAR TO MANTEL M-1452 ON REVERSE SIDE



# COLONIAL MANTEL M-1455

MORGAN

INDEX SHEET NO. 37



FULL SIZE PROFILE  
OF MANTEL

FULL SIZE  
PILASTER  
PLAN PROFILE



SCALE  $\frac{1}{4}$ "=1'-0"

MANTEL M-1455




SCALE  $\frac{3}{4}$ "=1'-0"



# COLONIAL MANTELS M-1456-7

MORGAN


INDEX SHEET NO:38



FULL SIZE  
SECTION OF  
PANEL MOLD



FULL SIZE PLAN THRU PILASTER



PLANS SECTIONS AND PROFILES SIMILAR  
TO MANTEL M-1455 ON REVERSE SIDE.

# COLONIAL MANTEL M-1458

MORGAN

INDEX SHEET NO. 39


FULL SIZE PROFILE OF MANTEL

FULL SIZE PROFILE  
PLAN THRU FRAME  
& PART OF PILASTER

MANTEL M-1458


CAP

FIREBRICK




FRONT ELEVATION

SECTION



ELEVATION SCALE  $\frac{1}{4}'' = 1'-0''$






PLAN SCALE  $\frac{3}{4}'' = 1'-0''$

FULL SIZE PROFILE OF PILASTER BASE

# COLONIAL CHINA CASES M-1553-4

MORGAN

INDEX SHEET NO. 40




COLONIAL CHINA CASE M-1555

**MORGAN**


**INDEX SHEET NO.4**

Fall 1930




## SECTION

**FRONT ELEVATION**  
SCALE  $\frac{3}{4}'' = 1'-0''$



ELEVATION  
SCALE  $\frac{1}{4}$ " = 1'-0"




# COLONIAL CHINA CASE M-1556

MORGAN

INDEX SHEET NO. 42


FULL SIZE PROFILE  
OF TRIM




SECTION

FRONT ELEVATION  
SCALE  $\frac{3}{4}''-1'-0''$


FULL SIZE PILASTER CAP



FULL SIZE PLAN OF PILASTER



ELEVATION  
SCALE  $\frac{1}{4}''-1'-0''$




FULL SIZE PILASTER BASE


# COLONIAL CHINA CASE M-1557

MORGAN


## INDEX SHEET NO.43




FULL SIZE PROFILE  
OF TRIM



FULL SIZE SECTION  
OF CROWN MOULD



FULL SIZE SECTION  
OF DRAWER





# COLONIAL CHINA CASES M-1558-9

MORGAN


## INDEX SHEET NO.44

FULL SIZE PROFILE OF CORNICE CAP




ELEVATION SCALE  $\frac{1}{4}$ "=1'-0"

HALF FRONT ELEVATIONS  
SCALE  $\frac{3}{4}$ "=1'-0"




SECTION



ELEVATION SCALE  $\frac{1}{4}$ "=1'-0"

FULL SIZE DETAIL OF PILASTER CAP






# COLONIAL CHINA CASE M-1560


MORGAN

# INDEX SHEET NO. 45

FULL SIZE PROFILE OF TRIM



ELEVATION  
SCALE  $\frac{1}{4}'' = 1'-0''$




# COLONIAL CHINA CASES M-1561-2

MORGAN


# INDEX SHEET NO-46

Fall 1930




FULL SIZE DETAIL  
OF PILASTER CAP

F.S.D. OF ARCH TRIM







FULL SIZE OF  
CORNICE CAP



CHINA CABINETS  
M-1562

13° P





SECTION

ELEVATION

HALF FRONT ELEVATIONS

SCALE  $\frac{3}{4}'' = 1'-0''$






SCALE  $3'' = 1'-0''$   
ELEVATION OF KEYSTONE - SEC.

# COLONIAL BOOKCASE M-1550


MORGAN

INDEX SHEET NO.47

FULL SIZE PROFILE OF TRIM



FULL SIZE PROFILE  
OF BASE






# COLONIAL BOOKCASE M-1551

MORGAN

INDEX SHEET NO:48




FULL SIZE PROFILE OF TRIM




# MISCELLANEOUS UNITS



# INDEX SHEET NO:49






ALL AT  
SCALE  $\frac{3}{4}'' = 1'-0''$



# COLONIAL LINEN CASES M-1565-6

MORGAN

# INDEX SHEET NO:50




# COLONIAL KITCHEN UNITS

MORGAN







# INDEX SHEET NO:51

- NOTE -  
ALL SIZES WITH EITHER  
GLAZED OR PANELLED  
DOORS.




SEC. B-B

## KEY TO SIZES OF SECTIONS



UPPER SECTIONS

A-LOWER SECTIONS SEC. A-A



SECTION ELEVATION  
SCALE  $\frac{1}{2}'' = 1'-0''$


ELEVATION  
SCALE  $\frac{1}{2}'' = 1'-0''$

SECTION A-A

# COLONIAL PORCH WORK

MORGAN

# INDEX SHEET NO:52




PORCH BALUSTERS




M-1959


FULL SIZE SECTION OF  
PORCH RAIL M-1954




M-1953



M-1951



M-1952




M-1950



FULL SIZE SECTION  
OF PORCH RAIL  
M-1956



PORCH WORK  
SCALE  $\frac{3}{4}$ " = 1'-0"



FULL SIZE SECTION  
OF PORCH RAIL  
M-1957



FULL SIZE SECTION OF  
PORCH RAIL M-1955



PORCH COLUMNS




PLANS


# COLONIAL GARAGE DOORS

**MORGAN**


## INDEX SHEET NO.53



**GARAGE DOORS  
SCALE  $\frac{3}{4}$ " = 1'-0"  
FURNISHED IN PAIRS**



**GARAGE DOORS**  
SCALE  $\frac{3}{4}": 1'-0"$   
**FURNISHED IN SETS OF THREE**





# Colonial Woodwork Details by Morgan

--for Use in the Drafting Room--

THESE details were prepared by prominent architects — members of the American Institute of Architects—in cooperation with other members of the Institute. All designs detailed were inspired by authentic examples of old Colonial originals. They supplement the complete illustrated catalog of "*Correct Woodwork for the Colonial Home.*"

All designs are made in the shops of the Morgan Woodwork Organization by craftsmen of long experience in producing woodwork of the finest quality and workmanship. Each item is carried in stock at conveniently located warehouses and furnished by authorized Local Distributors.

All woodwork of our manufacture is marked with the Morgan stamp of dependability. This is your assurance of the correctness of the detail and protects you against the possibility of substitution.

For prices, kinds of wood, and other information see the current Morgan Price Supplement.



Consult an Architect!

MORGAN WOODWORK ORGANIZATION  
SEVENTY-FIFTH YEAR

Digitized by



ASSOCIATION  
FOR  
PRESERVATION  
TECHNOLOGY,  
INTERNATIONAL  
[www.apti.org](http://www.apti.org)

BUILDING  
TECHNOLOGY  
HERITAGE  
LIBRARY

<https://archive.org/details/buildingtechnologyheritagelibrary>

From the collection of:

Mike Jackson, FAIA